

będzie działać przez wiele lat. Używanie niezatwierdzonych materiałów eksploatacyjnych może spowodować unieważnienie gwarancji. Gwarancja nie obejmuje materiałów eksploatacyjnych (lampy UV i płytek klejących), awarii spowodowanych niewłaściwym użytkowaniem, nieprawidłową obsługą lub niewłaściwym zastosowaniem.

CZYSZCZENIE

Czyszczenie należy przeprowadzać wyłącznie po uprzednim upewnieniu się, że urządzenie jest odłączone od sieci elektrycznej. Zaleca się, aby przeprowadzać czyszczenie urządzenia co miesiąc. Urządzenie należy dokładnie wytrzeć wilgotną szmatką, usuwając wszelkie nagromadzone zabrudzenia. Przed ponownym podłączeniem urządzenia do zasilania należy upewnić się, że jest ono całkowicie suche. Zalecamy czyszczenie urządzenia wyłącznie za pomocą wilgotnej szmatki, bez stosowania żadnych środków chemicznych poza łagodnym deterгентem.

SW - SÄKERHETSINFORMATION

Läs de här anvisningarna noggrant och förvara på en säker plats för framtida bruk.



- Den här apparaten ska hållas utom räckhåll för barn.
- Den här apparaten kan användas av barn från 8 års ålder, och av personer med nedsatt fysisk, sensorisk eller mental kapacitet eller bristande erfarenhet och kunskap om de får tillräcklig övervakning eller har givits tillräcklig instruktion avseende säker användning av apparaten, och förstår de faror den medför.
- Rengöring och underhåll får inte utföras av barn utan övervakning.
- Barn ska övervakas för att säkerställa att de inte leker med apparaten.
- Varning: Den här apparaten måste jordas. Om nätsladden är skadad måste den bytas ut mot en särskild sladd eller montering som är tillgänglig hos tillverkaren eller dess serviceombud.
- Den här apparaten är endast avsedd för användning inomhus.
- Den här apparaten får inte användas i lador, stall eller på liknande platser där det är sannolikt att brännbara ämnen eller explosivt damm kan finnas.

KABELINSTRUKTIONER

Ledningarna i nätkabeln är färgade enligt följande kod:

BLÅ = NEUTRAL
BRUN = STRÖMFÖRÄNDE
GUL & GRÖN = JORD

Eftersom färgerna på ledningen i nätkabeln till den här apparaten kanske inte överensstämmer med färgmarkeringar som identifierar terminalerna på din kontakt gör du så här:

- Den BLÅ ledningen måste kopplas till terminalen som är märkt med bokstaven N.
- Den BRUNA ledningen måste kopplas till terminalen som är märkt med bokstaven L.
- Den GULA & GRÖNA ledningen måste kopplas till terminalen som är märkt med bokstaven E eller symbolen ⚡

GARANTI

Besök vår webbplats eller kontakta din försäljningsrepresentant för information om garantin. Om den underhålls enligt rekommendationerna i denna bruksanvisning bör den fungera i många år. Användning av icke godkända förbrukningsvaror kan göra garantin ogiltig. Garantin omfattar inte förbrukningsvaror (UV-lampor och limplattor), haveri på grund av felaktig användning, felaktig drift eller användning i felaktig apparat.

RENGÖRING

Säkerställ att enheten är fränkopplad från elnätet innan rengöring påbörjas. Vi rekommenderar att rengöring utförs varje månad. Enheten torkas av noggrant med en fuktig trasa för att avlägsna all smuts. Se till att enheten är helt torr innan den kopplas in till elnätet igen. Vi rekommenderar att enheten bara rengörs med en fuktig trasa som inte innehåller några kemikalier utöver ett mildt rengöringsmedel.

IN THE BOX:

- 1 x IND35 Insect Light Trap
- 2 x 18" LED Long UV Lamps (Fitted)
- 1 x Universal Glueboard (Fitted)
- 2 x Fixing Screws and Wall Plugs
- 1 x IEC Removable Mains Cable

EQUIPMENT REQUIRED FOR INSTALL:


- Spirit Level (Advisable)
- Tape Measure
- Power Drill
- Masonry Drill Bit Ø6mm
- Phillips Screwdriver PH2

1. Positioning and Guidance | عرض ووجه دي دحتو دي | Positionierung und Anleitung |





Posicionamiento y orientación | Positionnement et orientation | Posizionamento e orientamento |

Positionering en begeleiding | Pozycjonowanie i wskazówki | Positionering och vägledning


Preferably, insect light traps should be installed preferably in the darkest place within the area. Do not position the unit close to windows, skylights or other sources of light, or where it may be obscured by furniture, doors or other obstacles. Ideally, insect light traps should be visible from every part of the area to be protected. Do not position above sinks, sources of steam, or food preparation areas. Insect light traps are designed to be in operation for 24 hours a day, ensuring your premises are kept free of flying insects. Insects are most attracted to insect light traps at night when there is no competition from daylight or other light sources.




2. Installation | تثبيت | Installation | Instalación | Installation | Installazione | Installatie | Instalação | Installation



3. Glue Board Maintenance | عار عا حول قنايص | Wartung der Klebeplatte | Mantenimiento del panel adhesivo | Remplacement de la plaque de glu | Manutenzione del pannello adesivo | Onderhoud van lijmplaat | Konserwacja tablicy klejowej | Byte av limark



4. UV/LED Maintenance | تيفتفنبلا قوف ءعشالا قنايص / LED | UV/LED-Wartung | Mantenimiento UV/LED | Remplacement du tube LED | Manutenzione UV/LED | UV/LED-onderhoud | Konserwacja UV/LED | Byte av UV/LED



SPECIFICATION / REPLACEMENT PARTS

Model	IND35
Voltage	110-230V ~ 50-60Hz
Dimensions (mm)	H 284mm x W 484mm x D 145mm
Weight (kg)	2.1kg
UV LED Lamps (Pack of 2)	1106002616
UV LED Lamps (Pack of 16)	1106002596
Glueboard White (Pack of 15)	1106002592
Glueboard EasyCount (Pack of 15)	1106002593



For private households: Information on Disposal for Users of WEEE

This symbol on the product(s) and / or accompanying documents means that used electrical and electronic equipment (WEEE) should not be mixed with general household waste. For proper treatment, recovery and recycling, please take this product(s) to designated collection points where it will be accepted free of charge. Alternatively, in some countries, you may be able to return your products to your local retailer upon purchase of an equivalent new product. Disposing of this product correctly will help save valuable resources and prevent any potential negative effects on human health and the environment, which could otherwise arise from inappropriate waste handling. Please contact your local authority for further details of your nearest designated collection point. Penalties may be applicable for incorrect disposal of this waste, in accordance with your national legislation.

For professional users in the European Union

If you wish to discard electrical and electronic equipment (EEE), please contact your dealer or supplier for further information.

For disposal in countries outside of the European Union

This symbol is only valid in the European Union (EU). If you wish to discard of this product, please contact your local authorities or dealer and ask for the correct method of disposal.




Pelsis Ltd, HG5 8PJ, UK | Pelsis Belgium NV, Bornem 2880
Pelsis LLC, Jackson, GA 30233, USA | pelsis.com



IND35 LED

Instruction booklet



IND35 LED

UK Part Number:
1106002706

EU Part Number:
1106002707

EN - SAFETY INFORMATION

Please read these instructions carefully and store in a safe place for future reference.



This appliance is to be kept out of the reach of children.

- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision instruction concerning use of the appliance in a safe way and understand the hazards involved.
- Cleaning and user maintenance shall not be made by children without supervision.
- Children should be supervised to ensure they do not play with the appliance.
- Warning: This appliance must be earthed. If the supply cord is damaged, it must be replaced with a special cord or assembly available from the manufacturer or its service agent.
- This appliance is for indoor use only.
- This appliance is not suitable for use in barns, stables, and similar locations or in locations where flammable vapour or explosive dust is likely to exist.

WIRING INSTRUCTIONS

The wires in the mains lead are coloured in accordance with the following code:

BLUE = NEUTRAL
BROWN = LIVE
YELLOW & GREEN = EARTH

As the colours of the wire in the mains lead of this appliance may not correspond with the colour marking identifying the terminals on your plug, proceed as follows:

- The wire which is coloured BLUE must be connected to the terminal which is marked with the letter N.
- The wire which is coloured BROWN must be connected to the terminal which is marked with the letter L.
- The wire which is coloured YELLOW & GREEN must be connected to the terminal which is marked with the letter E or the symbol ⚡

GUARANTEE

For the warranty details, please visit our website or contact your sales representative. If maintained as recommended in these instructions, it should continue to work for many years. Use of non-approved consumables may invalidate the guarantee. The guarantee does not cover consumables, (UV lamps and glueboards), breakdown due to misuse, incorrect operation or use in an incorrect application.

CLEANING

Cleaning should be carried out only after ensuring the unit is disconnected from the mains. It is recommended that cleaning is carried out monthly. The unit should be thoroughly wiped down with a damp cloth, removing any build-up of dirt. Ensure the unit is completely dry before reconnecting it to the power supply. We recommend to clean the unit using only a damp cloth which does not contain any

